






















Context	Shortcut	Button	Description
Application	O rganisation		Organize the windows with the default layout
Application	A ffichage		Show / Hide the display settings
Application	B andeau		Show / Hide the side panel
Application	CTRL F5		Show / Hide the subscription dialog
Application	F5		Update all subscriptions to the shared files
Application	CTRL +		Increase panoramic image brightness
Application	CTRL -		Decrease panoramic image brightness
Active panoramic view	D istance(& Laser)		Show / Hide the distance value under the cursor , and activate the 'laser' in the other view
Active panoramic view	P oints		Toggle the "no point" view mode
Active panoramic view	C ouleur		Toggle the gray scale view and the color view (if available)
Active panoramic view	R endering		Activate / disable the 3D rendering insed panoramic view
Active panoramic view	T ransparent		Activate / disable the transparent rendering on objects
Active panoramic view	H (UHD)		Toggle SCAN / UHD (Ultra Hight Def Image) (if available)
Active panoramic view	L		Synchronize the second view to the cursor in the first view, with the laser turned on (while pressing the key)
Active panoramic view	ALT		Hide the nearest stations (while pressing the key)
Active panoramic view	Backspace or Page down		History : previous
Active panoramic view	Maj + backspace or Page up		History : next
Active panoramic view	Arrows		Rotate the view
Active panoramic view	+ / -		Zoom in / zoom out
2D layout view	Arrows		pan the map
2D layout view	+ / -		Zoom in / zoom out
Polyline edition	INSERT		Insert a vertex
Polyline edition	SUPPR (with a selected vertex)		Delete the selected vertex
Item selected	X / Y / Z		Activate / disable the constraints on axis
Item selected	Q		Activate / disable the transplation mode on objects
Item selected	W		Active / désactive the rotation mode on objects
Item selected	ECHAP		Escape or finish the creation of the current object
Item selected	SUPPR		Delete the selected object
3D view	F1		Front view
3D view	F2		right view
3D view	F3		top view
3D view	F4		Toggle the perspective view and the isometric view
3D view	HOME		Extended zoom
3D view	Flèches		Pan in the view
3D view	+ / -		Zoom in / zoom out